



# Charisma Trifecta Stand™ - XP3N Series

1. Connect the lower frame to the base using the flat head screws and nuts provided, then attach the middle and upper frame using the remaining screws and nuts provided.
2. Insert the graphics into the frames. Graphic installation is detailed on the next page.




Single graphic

Two graphics

Three graphics

XP3N1 shown



# Charisma Trifecta Stand™ - XP3N Series

1. To install the graphic, take the corner with the pull tag on it and press about 6"-10" of silicone into the frame channel corner A. Repeat for the opposite corner B. Repeat for the next corner C. Lastly, repeat for the final corner D.  
This prevents the graphic from bunching up or stretching too much and will ensure a smooth and tight fit.
2. After all corners are pressed in, press the silicone into the frame channel at the mid-points on all four sides.
3. Press silicone into frame evenly between the corners and midpoints.
4. To remove the graphic from the frame, simply pull up on the pull tag.
5. Repeat graphic installation for reverse side (not shown).

