FrameGraphix Magnetic Signware Stand™ - TLS Series

1. Screw the frame onto the upright.
2. *For -RD and -SQ units*: Attach the upright to the base using the spring button connection. *For TLS1472 and TLS2472*: Attach frame to base using screws provided.
3. *For -MM units*: Attach magnetic graphic to steel surface.
4. *For -MR units*: Attach magnetic surface to metal surface, then attach metal graphic to magnetic surface.
5. *For the telescopic models -TP*: Loosen the clutch by turning the clutch counter-clockwise, then raise the upright to the desired height. Turn the clutch clockwise to lock the height position.

1. - TP (Telescopic)

1. - X (Fixed)

2. -RD

2. -SQ

2.

TLS1472 and TLS2472

4. -MR

Magnetic surface

Metal graphic

Magnetic surface

Metal graphic

3. -MM

Magnetic graphic

Magnetic graphic

5.

B. Raise up

C. Lock

A. Open

TLS2472-MM shown

TLS3-X-MM-SQ-V shown

TLS3-TP-MM-RD-H shown