

SETUP INSTRUCTIONS



General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.




- For Cleaning Metal, Plex, & Laminate Parts: Use a MILD NON-ABRASIVE cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure. Heat and UV exposure will warp and fade components.
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

Disassembly

- For loss prevention, tighten all setscrews and locks during disassembly




Hex Tool - Essential for Assembly




Part Identification - Numbering




MARNING




Spline Connection




Base Plate & Extrusion Connection





Extrusion & Lock Connection



Engaged Lock



DO NOT USE POWER TOOLS



LADDERS OR LIFTS MAY BE REQUIRED





ALL CONNECTIONS MUST BE TIGHTLY SECURED





Top View of Each Level


Backwall Components

















Order #XXXXX - Backwall Assembly


Item	Qty.	Description	
1	1	47.9975"h Lower Curved Extrusion	
1A	1	38.5"h Upper Curved Extrusion	
2	1	47.9975"h Lower Curved Extrusion	
2A	1	38.5"h Upper Curved Extrusion	
3	1	47.9975"h Lower Curved Extrusion	
3A	1	38.5"h Upper Curved Extrusion	
4	2	36.1425"h Backwall Support Extrusion	
5/5A	1/1	44"w Lower Horizontal Extrusion	
6/6A	1/1	44"w Upper Horizontal Extrusion	
7/7A	1/1	23"w Upper Horizontal Extrusion	

Steps:

- 1) Connect backwall upper and lower verticals together [1] to [1A], [2] to [2A] and [3] to [3A].
- 2) Connect horizontal extrusions together [5] to [5A] and [6] to [6A].
- 3) Attach horizontal assemblies [5/5A and 6/6A] between vertical assemblies [1/1A] and [2/2A].
- 4) Attach horizontal extrusions [7 and 7A] between vertical assemblies [2/2A and 3/3A].
- 5) Attach support leg extrusions [4] to back of verticals [1] and [3], see leg attachment detail.
- 6) Attach graphics to backwall where indicated.









Order #XXXXX - Counter Assembly

Item	Qty.	Description
8	1	Base Plate


1 37.476"h Vertical Extrusion

9A 1 Flange Plate

10 1 15.69"w Horizontal Extrusion11 1 18.5"w Horizontal Extrusion

Steps:


- 1) Attach base plate to vertical [9].
- 2) Connect horizontals [10] & [11] between vertical [9] and backwalll assembly.
- 3) Attach counter to upper horizontal [11] using mounting plate [9A]









Connect Vertical Extrusion to Base
Plate by placing lock into slot
and tighten with tool.





Counter Top Attachment

Insert screws located on underside of counter into holes on flange plate and secure with wing nuts.





Order #XXXXX - Header Assembly

Item Qty. Description

12/12A 1/1 6.0257"h Vertical Extrusion 13/13A 1/1 35.74"w Curved Horizontal

Steps:

- Connect upper curved horizontals [13] & [13A] together.
 Attach verticals [12] & [12A] to each end of
- horiozntals as shown.
- 3) Attach header to upper backwall horizontals.

